



## CABINPUMP Installation Checklist

**IMPORTANT** – This checklist must be read in conjunction with the CABINPUMP operating manual. Ensure CABINPUMP chamber lid remains closed at all times.

| Action                                                                                                                                                                                     | Check                    |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|
| 1. Place CABINPUMP unit in required location and ensure it is flat and level                                                                                                               | <input type="checkbox"/> |
| 2. Connect 4" waste from building into the pre-formed inlet position(s). Ensure unused inlets are capped off                                                                               | <input type="checkbox"/> |
| 3. Connect 63mm* pumping main to the CABINPUMP using the supplied compression fitting and provide frost protection if necessary.<br><i>*Preferred specification 63mm SDR17 PE100 Black</i> | <input type="checkbox"/> |
| 4. Connect the 32A plug into a suitable power supply                                                                                                                                       | <input type="checkbox"/> |
| 5. Double check inlet and outlet connections                                                                                                                                               | <input type="checkbox"/> |
| 6. Fill CABINPUMP ½ full with clean water through the connected inlet(s)                                                                                                                   | <input type="checkbox"/> |
| 7. If safe to do so, open control box cover and turn the power isolator to the 'ON' position                                                                                               | <input type="checkbox"/> |
| 8. Wait for 60 seconds for the system to program                                                                                                                                           | <input type="checkbox"/> |
| 9. Press and hold 'Pump 1' button until the 'HAND' light illuminates – continue to hold for 10 seconds after the pump has started then release                                             | <input type="checkbox"/> |
| 10. Press and hold 'Pump 2' button until the 'HAND' light illuminates – continue to hold for 10 seconds after the pump has started then release                                            | <input type="checkbox"/> |
| 11. Press 'Pump 1' button until the 'AUTO' light illuminates                                                                                                                               | <input type="checkbox"/> |
| 12. Press 'Pump 2' button until the 'AUTO' light illuminates                                                                                                                               | <input type="checkbox"/> |
| 13. Allow the CABINPUMP to fill again to test the automatic pumping cycle                                                                                                                  | <input type="checkbox"/> |
| 14. The system is now in automatic mode. Close and lock the control panel                                                                                                                  | <input type="checkbox"/> |

If you have any questions or queries, please contact us to speak to an engineer.

